


**Teradek Cube - Live Streaming to Facebook Live
- Infrastructure Mode**



Infrastructure Mode means you are connecting all devices to the same available wifi network or hotspot. The benefit of Infrastructure mode over Access Point Mode is that the viewing device will still have access to the internet for sharing or streaming.

One limitation of Infrastructure Mode is that if you are moving shoot locations you will need to keep re-connecting to local Wifi networks. This can be avoided by using a portable cellular hotspot.

Facebook requires a 24hr wait period after sign up before you can livestream. So plan ahead!

Teradek Cube Setup:

- Menu > System Setup > Factory Reset > **All**
- Network Setup > Wifi > **Infrastructure Mode**
- Network > Wifi > Setup > Scan for networks > Select a network.
- Network > Wifi > Status > IP address (this needs to be entered into web browser)




Cube Web UI Setup

Enter Cube IP address into web browser of choice
* Note -Computer must be on the same wifi network as the Cube

- Video Stream Output > Primary Stream > **H.264**
- Video Stream Output > Streaming Mode > **Internet Streaming**
- Video Stream Output > Provider > **Facebook**

Click 'Authorize Your Device' to open and log into Facebook Setup.



Facebook Web UI Setup:

You will be asked to approve permissions for Teradek Cube to post to your pages and confirm who can see your posts
Once authorized, return to the Cube web UI.

Cube Web UI Setup

- Primary Stream > Stream to > Choose destination (timeline, page, group)
- Title your stream, include a description and confirm privacy settings match those of your Facebook/Cube authorization.
- Click 'Apply' to save settings.

